lifts, locks, other hardware, etc.

Factory Sash:- All factory sash to be furnished and installed complete with mullions and frames, ventilated as shown, together with operating and other devices for convenient operation.

The lower ventilators to be operated with push bars, the upper to be operated with chains; the chains to be provided where called for. These operators for the upper and lower sash to be so installed as not to interfere with the curtains or shutters to be installed to darken the windows.

The sash to be grouted and pointed in place, glazed with 1/8" thick factory ribbed glass, as shown, and left wind, water and weather tight.

Where shown, lights are to be glazed with 28-gauge galvanized iron to keep out light, before the glass is placed in position.

Side-Wall Sash Puttying:- The sidewall sash is to be puttied, using approved steel sash putty; the putty to contain sufficient litharge so that it will harden quickly; the putty not to be painted until after it has formed a crust.

If it is necessary at any time to soften the putty, nothing but gasoline is to be used.

Painting:- All metal sash to be painted as specified under "Painting".